





LOCATION OF TRACTOR ENGINE SERIAL NUMBERS

Nuffield, Leyland, Marshall and JWD tractors.

This is a general guide only and is intended to help you identify your engine by locating the engine serial number. Whilst every effort is made to ensure the accuracy of the particulars contained in this document, modifications made to your tractor may affect the information specified. No responsibility is accepted for the incorrect supply of parts supplied or any other consequence that may arise as a result of information in this document not being in accord with modifications of vehicle specification changes which are subsequent to original factory specification. Also no responsibility is accepted for the incorrect supply of parts or any other consequence that may arise as a result of any misinterpretation of the information specified in this document.

<u>Engine</u>	<u>Fitted to</u>	<u>image</u>
<p><u>B.M.C. 4-CYLINDER DIESEL</u> The serial number of the BMC 4-cylinder diesel engine is stamped in the rear top corner on the right-hand side of the cylinder block under No.4 cylinder decompression screw.</p> <p><u>Examples:</u></p> <p>38TA/1178/D12345</p>	<p>Nuffield 4DM – 3.4 Nuffield 460 – 3.8T or 3.8TA Nuffield 10/60 – 3.8TA or 3.8TD Nuffield 4/65 – 3.8TD Leyland 384 – 3.8TD Leyland 344 – 3.4TD</p>	
<p><u>B.M.C. 3-CYLINDER DIESEL</u> The serial number of the BMC 3-cylinder diesel engine is stamped on a machined face on the forward lower right-hand side of the cylinder block just under the fuel injection pump coupling.</p> <p><u>Examples:</u></p> <p>25T/B/D10263 28TD/B/D256</p>	<p>Nuffield 3DL – 2.6 Nuffield 342 – 2.8 Nuffield 3/45 – 2.8TD</p>	

<p><u>B.M.C. 4-CYLINDER V.O. AND PETROL</u> The serial number of all V.O. and petrol engines is stamped on a disc attached to the right-hand side of the cylinder block.</p> <p><u>Examples:</u></p> <p>ETD/5121921 ETC/2/121959</p>	<p>Nuffield M3 Nuffield M4 Nuffield PM4 Nuffield MV3</p>	
<p><u>PERKINS DIESEL</u> The engine serial number of the Perkins engine is stamped on the right-hand side of the cylinder block just below the heater plug.</p> <p><u>Examples:</u></p> <p>OEA/2D/30040 OEA/2E/29236</p>	<p>DM4 (with Perkins P4 engine)</p>	


B.M.C. 948cc 4-CYLINDER DIESEL

The serial number of the BMC 948-cc 4-cylinder diesel engine is situated on a raised face on the right hand side of the cylinder block immediately below Nos. 2 and 3 heater plugs.

Example:

9T/216/1D2345

BMC Mini




B.M.C. 948cc 4-CYLINDER PETROL



The serial number of the BMC 948-cc 4-cylinder petrol engine is stamped on a plate secured to the right-hand side of the cylinder block immediately below No. 1 sparking plug.



Example:

9TA/216/P12345

BMC Mini



<p><u>B.M.C. 1500cc 4-CYLINDER DIESEL</u> The serial number of the BMC 1500-cc 4-cylinder diesel engine is stamped on a plate on the right-hand side of the cylinder block immediately below Nos. 2 and 3 heater plugs.</p> <p><u>Example:</u></p> <p>15T/216/D12345</p>	<p>Nuffield 4/25 Leyland 154</p>	
<p><u>B.M.C. 1622cc 4-CYLINDER PETROL</u> The serial number of the BMC 1622-cc 4-cylinder petrol engine is stamped on a plate secured to the right-hand side of the cylinder block immediately below Nos. 2 and 3 sparking plugs.</p> <p><u>Example:</u></p> <p>16T/216/P12345</p>	<p>Nuffield 4/25 Leyland 154</p>	


<p><u>LEYLAND 4/98 4-CYLINDER DIESEL</u> The serial number of the Leyland 4/98 4-cylinder engine is stamped on the top face of the cylinder block below No. 4 injector.</p> <p><u>Example:</u></p> <p>4/98NT/1480/2345</p>	<p>Leyland 344, 384, 255, 270, 262, 272, 462, 472. Leyland 602, 604, 702, 704, 802, 804.</p>	 <p>MP0001</p>
<p><u>PERKINS D3.152 3-CYLINDER DIESEL</u> The serial number of the Perkins D3.152 3-cylinder engine is stamped on the cylinder block adjacent to the fuel lift pump.</p> <p><u>Example:</u></p> <p>OE22657U574576F</p>	<p>Leyland 253, 245, 502</p>	 <p>MP0067</p>

LEYLAND 6/98 6-CYLINDER DIESEL
The serial number of the Leyland 6-cylinder diesel engine is stamped in the rear top corner on the right-hand side of the cylinder block under No. 4 cylinder decompression screw.

Example:

6/98NT/1330Sc/D12345

Leyland 285, 2100, 485, 4100.
Marshall 100, 115, 125, 145.




BMC 1800cc 4-CYLINDER DIESEL
The engine serial number of the BMC 1800-cc 4-cylinder diesel engine is stamped on a plate on the right-hand side of the cylinder block immediately below Nos. 2 and 3 heater plugs.

Example:

18T/789B/D12345

Leyland 184, 235, 302.



<p><u>PERKINS 4236</u> The engine serial number of the Perkins 4236 engine is stamped on the cylinder block above the injection pump.</p>	<p>Marshall 752XL, 754XL, 852XL, 854XL, 952XL, 954XL.</p> <p>JWD 274. 472. 284. 484. 294. 494.</p>	
---	--	--